Section Outline

1. Problems (with Solutions)

Problem 1: Crystal Growth


(based on a problem from the text)

Background: Crystalline forms of certain chemical compounds are used in various electronic devices, and it is often more desirable to have large crystals rather than small ones. Crystals of one particular compound are to be produced by a commercial process and an investigator wants to examine relationship between the size of the crystal, determined by its weight in grams, and the number of hours it takes the crystal to grow to its final size. The following data are from a laboratory study in which 14 crystals of various sizes were obtained by allowing the crystals to grow for different preselected amounts of time.


Weight	Time
(grams)	(hours)
0.08	2
1.12	4
4.43	6
4.98	8
4.92	10
7.18	12
5.57	14
8.40	16
8.81	18
10.81	20
11.16	22
10.12	24
13.12	26
15.04	28

- 1a. Fit and validate a model appropriate to the data.
- 1b. If a crystal is grown for 15 hours what is its predicted weight?
- 1c. Compute an interval that will contain the weight of the crystal with 95% confidence.
- 1d. For this process to be comercially viable suppose matched sets of six crystals will be grown for 24 hours in a sealed growth chamber under environmental conditions that are difficult to establish in the chamber. If every crystal in a set must end up within 2 g of the nominal weight of 12 grams with a probability of 0.9, does this process look viable? If not, could the apparent non-viability of the process be an artifact of the experiment design?

Crystal Growth Data




Crystal Growth Data with Straight Line Fit




Data, Residuals, and Other Diagnostic Values

			Raw	Standardized	Studentized
	Time	Mass	Residuals	Residuals	Residuals
1	2	0.08	-0.92828571	-1.01437798	-1.01571604
2	4	1.12	-0.89514286	-0.94518009	-0.94063181
3	6	4.43	1.40800000	1.44726304	1.52513102
4	8	4.98	0.95114286	0.95781297	0.95423719
5	10	4.92	-0.11571429	-0.11480784	-0.10998056
6	12	7.18	1.13742857	1.11766716	1.13054547
7	14	5.57	-1.47942857	-1.44681923	-1.52456449
8	16	8.40	0.34371429	0.33613819	0.32335372
9	18	8.81	-0.25314286	-0.24874481	-0.23877140
10	20	10.81	0.7400000	0.73420323	0.71928732
11	22	11.16	0.08314286	0.08372592	0.08018489
12	24	10.12	-1.96371429	-2.01847379	-2.37792910
13	26	13.12	0.02942857	0.03107359	0.02975189
14	28	15.04	0.94257143	1.02998860	1.03285058
			Cook's		
	Time	Mass	Cook's Distance		
1	Time	Mass		DFFITS	
2			Distance	DFFITS -0.59759491	
	2	0.08	Distance 0.1780896965 0.1147554994	DFFITS -0.59759491	
2	2 4	0.08 1.12	Distance 0.1780896965 0.1147554994 0.2001356438	DFFITS -0.59759491 -0.47676773	
2	2 4 6	0.08 1.12 4.43	Distance 0.1780896965 0.1147554994 0.2001356438	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057	
2 3 4	2 4 6 8	0.08 1.12 4.43 4.98	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596	
2 3 4 5	2 4 6 8 10	0.08 1.12 4.43 4.98 4.92	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722	
2 3 4 5 6	2 4 6 8 10 12	0.08 1.12 4.43 4.98 4.92 7.18	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064	
2 3 4 5 6 7	2 4 6 8 10 12 14	0.08 1.12 4.43 4.98 4.92 7.18 5.57	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691 0.0818464864	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064 0.09042294	
2 3 4 5 6 7 8	2 4 6 8 10 12 14 16	0.08 1.12 4.43 4.98 4.92 7.18 5.57 8.40	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691 0.0818464864 0.0044178117	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064 0.09042294 -0.07103870	
2 3 4 5 6 7 8 9	2 4 6 8 10 12 14 16 18	0.08 1.12 4.43 4.98 4.92 7.18 5.57 8.40 8.81	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691 0.0818464864 0.0044178117 0.0027384418	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064 0.09042294 -0.07103870 0.23829599	
2 3 4 5 6 7 8 9	2 4 6 8 10 12 14 16 18 20	0.08 1.12 4.43 4.98 4.92 7.18 5.57 8.40 8.81 10.81	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691 0.0818464864 0.0044178117 0.0027384418 0.0295822524	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064 0.09042294 -0.07103870 0.23829599 0.03034509	
2 3 4 5 6 7 8 9 10	2 4 6 8 10 12 14 16 18 20 22	0.08 1.12 4.43 4.98 4.92 7.18 5.57 8.40 8.81 10.81 11.16	Distance 0.1780896965 0.1147554994 0.2001356438 0.0656936227 0.0007233388 0.0552866691 0.0818464864 0.0044178117 0.0027384418 0.0295822524 0.0005019744 0.3892922269	DFFITS -0.59759491 -0.47676773 0.66670990 0.36112057 -0.03643596 0.33635722 -0.42633064 0.09042294 -0.07103870 0.23829599 0.03034509 -1.03950995	


Raw Residuals from Straight Line Fit vs Time




Standardized Residuals from Straight Line Fit vs Time





Residuals from Straight Line Fit vs Predicted Values




4 Plot of Residuals from Straight Line Fit












Leverage Values of Crystal Growth Times




Studentized Deleted Residuals from Straight Line Fit




Cook's Distances for Crystal Growth Data with Straight Line Fit



DFFITS for Crystal Growth Data with Straight Line Fit



Crystal Growth Data with Straight Line Fits Computed With and Without Point #12



Output from Straight Line Fit - All Data

N = 14

Residual Standard Error = 1.0618

Multiple R-Square = 0.9446

F-statistic = 204.5779 on 1 and 12 df, p-value = 0

coef std.err t.stat p.value Intercept 0.0014 0.5994 0.0024 0.9981 Time 0.5034 0.0352 14.3031 0.0000

Output from Straight Line Fit - Point #12 Removed

N = 13

Residual Standard Error = 0.9013

Multiple R-Square = 0.9623

F-statistic = 280.8466 on 1 and 11 df, p-value = 0

coef std.err t.stat p.value Intercept -0.1785 0.5144 -0.3470 0.7351 Time 0.5266 0.0314 16.7585 0.0000

Individual 95% Prediction Interval

Plugging in the numbers from the regression output yields:

Model 1: All Data

$$\hat{y}^* = 0.0014 + 0.5034 \times 15 = 7.5524$$

$$U = 2.178813(1.0618) \sqrt{1 + \frac{1}{14} + \frac{(15 - 15)^2}{910}}$$

= 2.2395

Model 2: Point #12 Removed

$$\hat{y}^* = -0.1785 + 0.5266 \times 15 = 7.7205$$

$$U = 2.200985(0.9013) \sqrt{1 + \frac{1}{13} + \frac{(15 - 14.30769)^2}{840}}$$

= 2.1374

Simultaneous 90% Prediction Intervals

Plugging in the numbers from the regression output yields:

Model 1: All Data

$$\hat{y}^* = 0.0014 + 0.5034 \times 24 = 12.083$$

$$U = 2.779473(1.0618) \sqrt{1 + \frac{1}{14} + \frac{(24 - 15)^2}{910}}$$

= 3.179

Model 2: Point #12 Removed

$$\hat{y}^* = -0.1785 + 0.5266 \times 24 = 12.4599$$

$$U = 2.820034(0.9013) \sqrt{1 + \frac{1}{13} + \frac{(24 - 14.30769)^2}{840}}$$

= 2.771

Computations of Coverage Factors for the Simultaneous Prediction Intervals

The coverage factor for the simultaneous intervals for Model 1 is chosen to be the lesser of:

$$t_{1-0.1/(2(6)),12} = 2.779473$$

and

$$\sqrt{6F_{0.9,6,12}} = 3.739805$$

The coverage factor for the simultaneous intervals for Model 2 is chosen to be the lesser of:

$$t_{1-0.1/(2(6)),11} = 2.820034$$

and

$$\sqrt{6F_{0.9,6,11}} = 3.78608$$


Problem 2: Measurement of Arsenic in Water (based on a problem from the text)

Background: An investigator wants to evaluate the performance of a new laboratory method for analyzing the concentration of arsenic (As) in water samples that is much cheaper than the existing method. If the new method is proven to be scientifically acceptable it will be adopted by environmental research groups for monitoring the quality of As in industrial waste water. To investigate the relationship between the measured concentrations of As and the actual concentrations, the investigator makes several water samples containing known (preselected) amounts of As. These water samples are analyzed by a laboratory technician (who is unaware of the actual amount of As in these solutions) using the new method of analysis. The concentrations are reported in ug/ml. The data are listed below.


Measured	True	Measured	True
Concentration	Concentration	Concentration	Concentration
(ug/ml)	(ug/ml)	(ug/ml)	(ug/ml)
0.17	0	3.91	4
0.25	0	3.90	4
0.01	0	3.61	4
0.12	0	4.27	4
1.25	1	4.88	5
0.86	1	5.33	5
1.25	1	4.96	5
1.10	1	4.98	5
2.01	2	6.09	6
2.03	2	6.17	6
2.14	2	6.07	6
1.74	2	5.97	6
3.18	3	6.67	7
2.99	3	7.02	7
3.23	3	7.14	7
3.37	3	7.30	7

- 2a. Fit and validate a model appropriate to the data.
- 2b. What is the estimated concentration of As in a solution which gives a measurement result of 1.32 ug/ml? What is the expanded uncertainty of this result at the 95% confidence level?
- 2c. Compute a 95% confidence interval for the true concentration of As in a solution which gives a measurement result of 8.87 ug/ml.


As in Water Data




As in Water Data with Straight Line Fit




Residuals from Straight Line Fit vs True As Concentration





Residuals from Straight Line Fit vs Predicted Values




4 Plot of Residuals from Straight Line Fit












Leverage Values of True As Concentrations




Studentized Deleted Residuals from Straight Line Fit




Cook's Distances for As in Water Data with Straight Line Fit



DFFITS for As in Water Data with Straight Line Fit



As in Water Data with Straight Line Fits Computed With and Without Point #29



Output from Straight Line Fit - All Data

N = 32

Residual Standard Error = 0.1875

Multiple R-Square = 0.9936

F-statistic = 4663.009 on 1 and 30 df, p-value = 0

coef std.err t.stat p.value Intercept 0.1046 0.0605 1.7284 0.0942 True Conc 0.9877 0.0145 68.2862 0.0000

Output from Straight Line Fit - With Point #29 Removed

N = 31

Residual Standard Error = 0.178

Multiple R-Square = 0.9941

F-statistic = 4862.312 on 1 and 29 df, p-value = 0

coef std.err t.stat p.value Intercept 0.0884 0.0580 1.5242 0.1383 True Conc 0.9958 0.0143 69.7303 0.0000

95% Calibration Interval Using All Data

$$\hat{x}^* = \frac{1.32 - 0.1046}{0.9877} = 1.2305$$

$$U = 2.042272 \sqrt{\frac{0.1875^2}{0.9877^2}} (1 + \frac{1}{32} + \frac{(1.2305 - 3.5)}{168}$$
$$= 0.3995$$

$$c = \frac{2.042272^2 \times 0.1875^2}{0.9877^2 \times 168} \approx 0.0009$$

95% Calibration Interval Using All Data

$$\hat{x}^* = \frac{8.87 - 0.1046}{0.9877} = 8.8746$$

$$U = 2.042272 \sqrt{\frac{0.1875^2}{0.9877^2}} (1 + \frac{1}{32} + \frac{(8.8746 - 3.5)}{168})$$
$$= 0.4253$$

$$c = \frac{2.042272^2 \times 0.1875^2}{0.9877^2 \times 168} \approx 0.0009$$

Problem 3: Calibration of an Optical Measurement Method (based on a problem from the text)


Background: It is well known that when a beam of light is passed through a chemical solution a certain fraction of the indcident light will be absorbed or reflected and the remainder will be transmitted. The intensity of the transmitted light decreases as the concentration of the chemical solution increases. This fact is often used to determine concentrations of various chemicals in solution. The data listed below are from an experiment in which several solutions of known concentrations of a pure chemical were used to measure the amount of transmitted light to determine the relationship between the optical readings and the true concentrations of the chemical.

Optical Reading (relative units)	True Concentration (mg/1)
2.86	0
2.64	0
1.57	1
1.24	1
0.45	2
1.02	2
0.65	3
0.18	3
0.15	4
0.01	4
0.04	5
0.36	5


3a. Suppose scientific theory suggests that the optical readings should be related to the true concentrations by an exponential relationship of the form y = b1+b2*exp(-b3*x). Fit the theoretical model to the data and validate the quality of the fit.

3b. Compute a 95% confidence interval for the true concentration of the chemical when the optical method gives a reading of 2.13 units.


Optical Measurement System Calibration Data




Optical Measurement System Calibration Data with Exponential Fit




Residuals from Exponential Fit vs True Concentration





Residuals from Exponential Fit vs Predicted Values




4 Plot of Residuals from Exponential Fit









Approximate Calibration Intervals by Inversion of Prediction Intervals

The basic steps to this approach of getting a calibration interval are:

1. solve the equation

$$f(x^*; \hat{\beta}_1, \dots, \hat{\beta}_p) - y^* = 0$$

to get an estimate of x^* ,

2. solve the equation

$$f(x^*; \hat{\beta}_1, \dots, \hat{\beta}_p) + U(x^*) - y^* = 0$$

to get the lower confidence bound for x^* ,

3. solve the equation

$$f(x^*; \hat{\beta}_1, \dots, \hat{\beta}_p) - U(x^*) - y^* = 0$$

to get the upper confidence bound for x^* ,

where
$$U(x^*) = t_{1-\alpha/2,n-p} \sqrt{s^2 + \vec{d}^*TV\vec{d}^*}$$
 as given on p. 233.

Computing the Estimate of x^*

The equation for estimating x^* for this problem is:

$$0.0287622 + 2.7232700 \exp(-0.6827710\hat{x}^*) - 2.13 = 0$$

Solving this equation numerically with generic nonlinear root-finding software yields the estimate $\hat{x}^* = 0.3798$

This equation can actually be solved analytically, but the that is not typically easy to do for most nonlinear models. A numeric approach is usually necessary for the computation of the confidence bounds too.

Computing $U(x^*)$

$$d^* = \begin{pmatrix} 0.0287622 \\ \exp(-0.682771\hat{x}^*) \\ -(2.72327)\hat{x}^* \exp(-0.682771\hat{x}^*) \end{pmatrix}$$

V can be obtained from the output from the fit by scaling the correlation matrix using the standard deviations of the estimated parameters:

```
1.000*0.172*0.172 -0.678*0.172*0.211  0.846*0.172*0.142
V = -0.678*0.172*0.211  1.000*0.211*0.211 -0.395*0.211*0.142
0.846*0.172*0.142 -0.395*0.211*0.142  1.000*0.142*0.142
```

Computing $U(x^*)$

Doing the matrix multiplication symbolically if necessary and plugging these pieces into equations 2 and 3 on page 311 and solving gives the upper and lower confidence bounds for the calibration interval.

For this problem the interval turns out to be:

(-0.0384, 0.3798, 1.0436)